





Fugoo Tough Power Button Replacement

Written By: Daniel




Step 1 — Power Button





- Begin by unscrewing the four 10.72mm corner screws using the h2.0 screwdriver.
- Using the h1.5 screwdriver remove remaining 6-5.79mm screws on the front of the speaker.
- Pull front part of shell away from back part of shell.

Step 2



- Change to the h1.3 head. Remove all 4-5.57mm screws on both speaker covers
- Pull on the speaker covers, thus removing them
- Rotate the speaker 180 degrees and then remove 4-5.57 screws on the side speaker that has the power/bluetooth buttons
- Pull apart the side speaker and its casing away from the body of the Fugoo

Step 3



- After pulling apart the side speaker and its casing you will see both the power and Bluetooth buttons on the underside of the circuit board
- The next step would be to un-solder the power button and replace it on the motherboard

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-08 04:28:06 PM.